


FH1 Foundationless Jib Crane Assembly Details



WARNING! ALL LIFT CRANES INC. FOUNDATIONLESS CRANES MUST MEET THE FOLLOWING SPECIFICATIONS AND GUIDELINES: Existing concrete must be a minimum of 12" thick reinforced with minimum 3,000psi (5 bag mix), soil pressure must support 2,500psf. Concrete in and around the area (10' x 10') of the base plate must be free of cracks and must appear in good condition.

- If the concrete conditions are not met, refer to the manufacturer's standard foundation requirement.
- Anchors must have an embedment of at least 10".
- Customer/installer is responsible for determining the adequacy of the concrete floor and correct anchors to be used.
- Grout is recommended under the base plate to level the mast.
- 10' x 10' square area (5' perimeter) where jib is installed must be free of cracks, seams, joints, walls and delamination.
- Jib must be professionally inspected once a month.

Epoxy Anchors

- Drill Bit 1-1/8" Dia.
- 1"-8UNC x 14" Rod
- 2 Nuts & 1 Washer
- Clean Holes Prior to Injection of Epoxy
- Fill Hole 1/2 to 2/3 with Epoxy then Insert Rod
- See Epoxy Tube for Cure Times
- For further instructions see insert provided with Epoxy Tube



All Lift Cranes Inc.
2127 W Nordale Dr
Appleton, WI 54914

Date: 12/2/2018	Capacity 1/2 Ton	By: JK
FH1 Foundationless Assembly Details		
		Drawing No: FH1-Assembly